



2245 B Fortune Drive, San Jose, CA 95131  
 Phone: (408) 433-1941, Fax: (408) 433-1943  
 e-mail: mail@rftechniques.com

## Ordering Instructions

S- Soldered B- Brazed	1 - Resistor 2 - Attenuator 3 - Termination	Package Style	Average Power	None- BeO A-AIN	xxx- Resistance (Ohm)
--------------------------	---	------------------	------------------	--------------------	-----------------------------

**Example:** 1Q300050 (300 Watts 50 Ohm Brazed Resistor)  
 S1Q300050 (300 Watts 50 Ohm Soldered Resistor)  
 S1Q300A050( 300 Watts 50 Ohm AIN Soldered Resistor)

	1	Q	300		xxx
Brazed Part	Resistor	Package Style	Average Power	BeO	Resistance (Ohm)
S	1	Q	300		xxx
Soldered part	Resistor	Package Style	Average Power	BeO	Resistance (Ohm)
S	1	Q	300	A	xxx
Soldered part	Resistor	Package Style	Average Power	AIN	Resistance (Ohm)